

Start the test as soon as you receive the device. It must be returned to the lab by the expiration date. The test duration is 91-365 days. Do not tamper with the VOID sticker or open the black plastic housing of the device. Make sure you don't open the sealed plastic bag until you are ready to start the test. It is important that the device stays in place throughout the duration of the test. The results of this test will be an average of the entire test duration. The report will not include day-to-day measurements.

## IS YOUR HOME SAFE?



## LONG-TERM ALPHA TRACK RADON IN AIR TEST



SCAN TO REGISTER YOUR DEVICE

## TEST INSTRUCTIONS

ACCUSTARLABS.COM/AT

Every space is different, but in general, deploy the kit at eye level to knee level; avoid drafts, moisture, and direct sunlight.



Don't place the device on stone surfaces or directly under blowing air.

**Where to NOT Test:** Kitchens, bathrooms, laundry rooms, closets, crawlspaces, or any area with humidity over 80%.

If you are testing for a real estate transaction, place 2 devices side by side, 4 inches apart.



Perform the test in the lowest livable area of the house. The location must be at least 3 feet from any door or window, 12 inches from exterior wall, 2-5 feet from the floor or ceiling, and 4 inches from other objects.

## CHOOSE A TEST LOCATION

### DISCLAIMER:

Failure to follow the testing instructions or protocols may result in an invalid test.

These instructions cannot anticipate or address every condition that arises when performing a radon test. Some states have regulations regarding radon testing. If you have questions about your state's requirements please contact your State Radon Office.

### Contact Us:

Radon Lab  
2 Saber Way  
Ward Hill, MA 01835

Tel. 800-767-3703  
www.accustarlabs.com/at

MEB# 90122

## RETURNING DEVICE(S) TO LAB

## TEST REPORTS

**Complete the Data Form online and return the closed device to our lab right away.** The lab must receive your device before the expiration date and no more than 30 days after the end of the test. For your convenience, the test kit includes a return USPS Mailer. If guaranteed delivery is needed, we recommend that you return your test device(s) via UPS or FedEx. Our lab is not responsible for any mail delays resulting in invalid results, nor any costs associated with upgraded shipping methods. No deliveries are accepted on weekends or holidays.



Results are usually available within 2-4 weeks of receipt by the lab, but may take longer during times of increased volume.

Visit [accustarlabs.com/at](http://accustarlabs.com/at) to access information about your radon test. You must have your device number(s) and zip code of the property tested.

Please contact us to request printed reports.

### Amended Reports

If your test report is incomplete due to errors or missing information, you must send the required information in writing, by mail, email, or on our website.



# QUICK START GUIDE

## BEFORE YOU BEGIN!

- Scan the QR code with your mobile phone or visit [accustarlabs.com/at](https://accustarlabs.com/at) to register device and fill out Data Form.
- Ensure that testing guidelines are followed. Scan the QR code for more information.
- **DO NOT** open the sealed plastic bag until you are ready to start your test.
- **RECORD YOUR DEVICE NUMBER(S):** \_\_\_\_\_



KEEP FOR YOUR RECORD

## Start Test

- 1 Test Instructions**  
Read the instructions thoroughly and scan the QR code or visit our website for more detailed instructions and supplementary video.



- 2 Record Start of Test Information**  
Once your device is registered and the start date is recorded on the online Data Form, you can begin your test.

- 3 Begin the Test**  
Cut or tear open the plastic bag that contains the Alpha Track. Set the device in the selected test location.



Leave the test in place for 91-365 days.



## QUESTIONS? CALL US!

800-767-3703

You must have your device number(s) and zip code of the property tested.

**Details and videos online:**  
[accustarlabs.com/at](https://accustarlabs.com/at)



## End Test

AFTER 91-365 DAYS AND PRIOR TO EXPIRATION DATE

- 4 End the Test**  
Place the device in the return mailer.



- 5 Record End Date**  
Scan the QR code at the top of page or visit [accustarlabs.com/at](https://accustarlabs.com/at) to complete the end of test information on the Data Form.

Double kits will have two test devices.

- 6 Return Device to Laboratory**



Using the prepaid USPS mailer, return the device to the lab. Devices received after 30 days may be invalid.

## Getting Your Report

You will receive your report 2-4 weeks after the lab receives your device.

You may also view your report at [accustarlabs.com/at](https://accustarlabs.com/at), where you will find additional information and resources regarding your report.

## TIME SENSITIVE!

UPON COMPLETION, RETURN TEST AS SOON AS POSSIBLE. SEE REVERSE SIDE FOR DETAILS.

expose for a duration of

91-365  
DAYS

